

**User Guide – MODBUS protocol
Firmware Version : 7100**

DAT 3024

PRELIMINAR DESCRIPTION

All the data variables shared by a Modbus module are shown in tables, where each data is linked to one address. Each data can be of two types:

- “COIL”, composed by a single bit, can be associated to digital input (switch), digital outputs (relays), logic states (alarms).
- “REGISTER”, composed by 2 bytes (16 bits), can be associated to analog input or outputs, variables, set-point, etc...

A register can also include the image of more coils, for example the 16 digital inputs of a device can be read and write as bit, one by one, addressing the relative coil, or they can be read or write as a single 16-bit port addressing the associated register, where for example the last significant bit will respond to the first coil.

In the Modbus protocol, coils and registers are divided in banks:
0xxxx and 1xxxx = Coils (bits)
3xxxx and 4xxxx = Registers (words)

REGISTERS TABLE

Registro	Description	Accesso	E ² P
40001	Test	R/W	
40002	Firmware Version	R	
40003		R	
40004	Device Name	R/W	*
40005		R/W	*
40006	Communication	R/W	*
40007	Address	R/W	*
40008	RX/TX Delay	R/W	*
40009	Watchdog Timer	R/W	*
40010	Coils	R/W	
40011	Calibration	R/W	
40012	Slew-Rate	R/W	*
40013	-- (reserved)	R/W	*
40014	Output Type	R/W	*
40015	Output # 0	R/W	
40016	Output # 1	R/W	
40017	Output # 2	R/W	
40018	Output # 3	R/W	
40019	-- (reserved)	R/W	
40020	-- (reserved)	R/W	
40021	-- (reserved)	R/W	
40022	-- (reserved)	R/W	
40023	PowerUp/Safe Output # 0	R/W	*
40024	PowerUp/Safe Output # 1	R/W	*
40025	PowerUp/Safe Output # 2	R/W	*
40026	PowerUp/Safe Output # 3	R/W	*
40027	-- (reserved)	R/W	*
40028	-- (reserved)	R/W	*
40029	-- (reserved)	R/W	*
40030	-- (reserved)	R/W	*

NOTE:

The registers marked with ' * ' in the ' E²P ' column are saved in EEPROM each time they are written, to be automatically reloaded to each power-on of the device.

COILS TABLE

Coil	Description	Access	E ² P
00009	Watchdog Enable	R/W	
00010	Watchdog Event	R/W	
00011	PowerUp Event	R/W	

IMPLEMENTED MODBUS FUNCTIONS

Function	Description
01	Read multiple coils (0xxxx bank)
02	Read multiple coils (1xxxx bank)
03	Read multiple registers (4xxxx bank)
04	Read multiple registers (3xxxx bank)
05	Write single coil
06	Write single register
15	Write multiple coils
16	Write multiple registers
08	Diagnostic

NOTE:

For DAT3000 series devices, the bank 0xxxx is a mirror of bank 1xxxx, as the 3xxxx bank is a mirror of bank 4xxxx, as for i.e. the first register can be read indifferently as 30001 (with the function 04) or 40001 (with the function 03)

REGISTER DESCRIPTION

40001 : TEST

This register is used to perform the following functions:
 - Analog inputs calibration (see the "Procedures" section).
 - Synchronized sampling (see the "Procedures" section).

40002 / 40003 : FIRMWARE VERSION

Read-only 2-register field, that hold the manufacturer firmware identifier.
 - Manufacturer default: 7100 (hex)


40004 / 40005 : DEVICE NAME

2-registers field (4 byte or 4 ASCII characters) user free, that can hold the device name or a function identifier. Each byte can be written with each value from 0 to 255, than ASCII characters too.
 - Manufacturer default: "3024" (ASCII).

40006 : COMMUNICATION

Set the bits of this register as shown in the following table, to set the baud-rate, the bit number, the parity type and the protocol type.
 - Manufacturer default: 38400 bps, RTU mode

Bit	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Desc.	-	-	-	-	-	-	-	-	-	M	P1	P0	N	B2	B1	B0



NOTES:

- the bit number is ignored, as for in ASCII mode it is fixed to 7 and in RTU mode it is fixed to 8.
- In RTU mode the parity is ignored (parity NONE)

40007 : ADDRESS

Specify the net address of the device; there are allowed the address from 1 to 255.
 Each device connected to the same net must have a unique address.
 The address 255 is used for broadcast functions (i.e. synchronized sampling)
 - Manufacturer default: 01

40008 : RX/TX DELAY

Specify the value of the delay between the reception of a command and the response transmission, indicated in milliseconds.
 - Manufacturer default: 1 (1 ms.)

40009 : WATCHDOG TIMER

Specify the value of the WatchDog Timer (see the "Procedures" section), indicated in steps of 0.5 seconds.
 - Manufacturer default: 10 (5 sec.)

40010 : COILS

This register is a mirror of the coils table: each bit of this register corresponds to a coil, as shown in the following table.

Bit	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Coil	-	-	-	-	-	-	-	-	-	-	-	-	-	11	10	09

40011 : CALIBRATION

This register is used to perform the output calibration function (see the "Procedures" section).

40012 : ANALOG OUTPUTS SLEW-RATE SETTINGS

Specify the programming of the slew-rate (rise time) of analog outputs. The value for each output is composed by 4 bits, as shown in the table.
 - Manufacturer default: 0Ch (Immediate)

Bit	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Desc.	Slr output #3				Slr output #2				Slr output #1				Slr output #0			

Value	V/s	mA/s
00h	Disabled	
01h	0.15	0.30
02h	0.30	0.60
03h	0.60	1.20
04h	1.20	2.40
05h	2.40	4.80
06h	4.80	9.60
07h	9.60	19.2
08h	19.2	38.4
09h	38.4	76.8
0Ah	76.8	153
0Bh	153	306
0Ch	Immediate	

40014 : OUTPUT TYPE CONFIGURATION

Each bit of this register corresponds to the programming of the output type for each channel (1 = voltage , 0 = current) ; all the outputs can be programmed independently as voltage or current.

- Manufacturer default: all 1 (voltage)

Bit	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Canale	-	-	-	-	-	-	-	-	-	-	-	-	#3	#2	#1	#0

40015 : ANALOG OUTPUT VALUE # 0

40016 : ANALOG OUTPUT VALUE # 1

40017 : ANALOG OUTPUT VALUE # 2

40018 : ANALOG OUTPUT VALUE # 3

This register allow to drive directly the output value.

The values are expressed in mV for the voltage outputs and in uA for the current outputs:

0 = 0 mA 0 = 0 V
20000 = 20 mA 10000 = 10 V

40023 : POWERUP / SAFE OUTPUT VALUE # 0

40024 : POWERUP / SAFE OUTPUT VALUE # 1

40025 : POWERUP / SAFE OUTPUT VALUE # 2

40026 : POWERUP / SAFE OUTPUT VALUE # 3

When the device is tuned-on (PowerUp) and in case of watchdog alarm (Safe), the outputs are automatically forced to the value specified in this register.

- Manufacturer default: 0

The values are expressed in mV for the voltage outputs and in uA for the current outputs:

0 = 0 mA 0 = 0 V
20000 = 20 mA 10000 = 10 V

COILS DESCRIPTION

00009 : WATCHDOG ALARM ENABLE

Enable the WatchDog alarm. If the alarm is enabled and the device does not receive any command for a time longer than the time specified in the 40009 register, the WatchDog alarm Event coil is forced to 1 (see the "Procedures" section).

0 = Watchdog alarm disabled

1 = Watchdog alarm enabled

00010 : WATCHDOG ALARM EVENT

This coil indicates the condition of WatchDog Alarm. If the alarm is enabled and the device does not receive any command for a time longer than the time specified in the 40009 register, this coil is forced to 1. To return from the alarm condition, set this coil to 0.

0 = Normal Condition

1 = Alarm Condition

00011 : POWER-UP EVENT

This coil is forced to 1 at each power-on of the device; this state indicates that the device has been switched off. It is possible to know if a reset of the device is happened clearing this coil and monitoring its state.

0 = reset not happened

1 = reset happened

PROCEDURES

HOW TO USE THE "INIT" FUNCTION

If the exact configuration of a module is unknown, it can result impossible to establish a communication with it.

The "INIT" function gives a solution to this trouble:

- Connect to the RS485 net only the device to configure.
- Turn off the device.
- Connect the INIT pin (D) to the GND pin (C).
- Turn on the device.
- Ensures that the "PWR" green LED on the front of the enclosure is lighted.

If not, control the voltage supply connections (I and J pins) and RS485 net connections (A and B pins).

If the supply connection is right, and the led still unlighted, it can be necessary to invert the RS485 pins connection.

- Set the communication port to these values:
 - baud-rate = 9600 bps
 - parity = None
 - n° bits = 8
 - stop bits = 1
- The device now communicates at the address 01 with the RTU protocol.
- Read or program the desired settings on the registers:
 - 40006 : "Communication" for the baud-rate setting
 - 40007 : "Address" for the net address of the device
- Turn off the device.
- Disconnect the INIT pin from the GND pin.
- Turn on the device.
- Set the communication port at the baud-rate programmed in the 40006 register.
- The device now communicates with the address programmed in the 40007 register.

NOTE: The default manufacturer programming is the following:

- Address : 01
- Baud-rate : 38400 bps
- Protocol : RTU

WATCHDOG

The modules has been provided of a Host Watchdog timer which, when it is enabled, makes to start the alarm each time the communication between the module and the host is inactive for a period time greater then the programmed one. When the alarm goes on, the values of the outputs are automatically converted to the values set as 'safety value', that corresponding to the state in which the outputs must be putted, and therefore the actuators are putted, to avoid damages to the system in case of failure. Moreover, under the alarm condition the green LED on the front of the enclosure is blinking and the "Watchdog Event" coil is forced to 1.

To return from the alarm condition, reset the coil "Watchdog Event" coil: the LED stop blinking and it is possible to set the outputs.

There is also a Module Watchdog timer that monitor the internal CPU work and is active when the CPU don't function correctly for any reason, and resets the module. After the reset, all outputs will assume their initial default value ("power up value"), that may be different to the output value after the reset.

CALIBRATION

The procedure of calibration is performed in factory on all the modules during the testing phase. However it can be convenient to make another calibration of the module according to the requirements of the user. To make this, it is necessary to use precision instruments and to correctly perform all the necessary steps, because any error reduces the accuracy and the good operation of the device.

To re-calibrate the device, follow this procedure:

- 1 – Turn on the device in INIT condition
- 2 – Connect a multimeter (voltage or current) to the terminals of the output to be calibrated.
- 3 – Program the output type to be calibrated (voltage or current)
- 4 – Set the output to 0, writing the value in the relative register (40015 ÷ 40018)
- 5 – Write 0 in the "Calibration" register (40011)
- 6 – Write on the "Test" register (40001) one of these values, depending of the output to be calibrated:
 - 21 – output # 0 23 – output # 2
 - 22 – output # 1 24 – output # 3
- 7 – Write 10000 (for voltage) or 20000 (for current) in the "Calibration" register (40011)
- 8 – Write on the "Test" register (40001) one of these values, depending of the output to be calibrated:
 - 31 – output # 0 33 – output # 2
 - 32 – output # 1 34 – output # 3
- 9 – Set the output to 0, writing the value in the relative register (40015 ÷ 40018)
- 10 – Read on the multimeter the analog output value
- 11 – Write the read value (expressed in mV or uA) in the "Calibration" register (40011)
- 12 – Write on the "Test" register (40001) one of these values, depending of the output to be calibrated:
 - 21 – output # 0 23 – output # 2
 - 22 – output # 1 24 – output # 3
- 13 – Set the output to the full-scale value (10000 or 20000), writing the value in the relative register (40015 ÷ 40018)
- 14 – Read on the multimeter the analog output value
- 15 – Write the read value (expressed in mV or uA) in the "Calibration" register (40011)
- 16 – Write on the "Test" register (40001) one of these values, depending of the output to be calibrated:
 - 31 – output # 0 33 – output # 2
 - 32 – output # 1 34 – output # 3
- 17 – Repeat point 2 to 16 for each output type and for each output channel to be calibrated.